



## PARTS CATALOG

REPLACEMENT PARTS, UPGRADES & ACCESSORIES



SCAN TO SHOP ONLINE

+1-800-933-0404 | [sales@plattcoiler.com](mailto:sales@plattcoiler.com)  
5627 Airline Hwy, Fruitport, MI 49415  
[www.plattcoiler.com](http://www.plattcoiler.com)

TABLE OF CONTENTS

**World Model 3000** ..... 2

    Air Cutter Components ..... 2

        Cutter Dies ..... 8

    Coiler Base Components ..... 10

    Coiling Head Components ..... 12

        Friction Drive Unit Components ..... 19

        Spindle Components ..... 22

        Drive Sleeves ..... 27

        Nose Caps ..... 29

    Gate Components ..... 30

    Isolator Unit Components ..... 33

    PLC and Electrical Components ..... 36

        Cables and Connectors ..... 36

        Electrical Control Unit Components ..... 37

        Motors and Motor Components ..... 39

    Spool Tower Components ..... 40

## WORLD MODEL 3000

### AIR CUTTER COMPONENTS



#### **CU-700-2: 2 1/2" CYLINDER AIR CUTTER, COMPLETE**

2 1/2" cylinder air cutter, complete

---



#### **CU-700-3: 3 1/4 CYLINDER AIR CUTTER, COMPLETE**

3 1/4 cylinder air cutter, complete

---



#### **CU-701-2: CUTTER DIE BLOCK WITH 1" HOLE**

Cutter die block with 1" hole

---



#### **CU-701-3: CUTTER DIE BLOCK WITH 1 1/4" HOLE**

Cutter die block with 1 1/4" hole

---



#### **CU-702: DIE LOCKING STUD FOR 3 1/4 CYLINDER CUTTER**

Die locking stud for 3 1/4 cylinder cutter

---



#### **CU-705-3: CUTTER BLADE ROUND 2" DIA.**

Cutter blade round 2" dia.

---



#### **CU-706: CUTTER BLADE SCREW AND NUT**

Cutter blade screw & nut

---



#### **CU-707-2: CUTTER BLADE HOLDER (1 1/2")**

Cutter blade holder (1 1/2")

---



### **CU-707-3: CUTTER BLADE HOLDER**

Cutter blade holder

---



### **CU-708-2: PLUNGER BARS FOR 2 1/2" CUTTER (2 PARTS)**

Plunger bars for 2 1/2" cutter (2 parts)

---



### **CU-708-3: PLUNGER BARS - 3 IN. CYLINDER**

Plunger bars - 3 in. cylinder

---



### **CU-709-2: DIE BLOCK SUPPORT RODS & NUTS (SET)**

Die block support rods & nuts (set)

---



### **CU-709-3: DIE BLOCK SUPPORT RODS & NUTS (SET)**

Die block support rods & nuts (set)

---



### **CU-710-2: PLUNGER SPRING SUPPORT PLATE (2 1/2")**

Plunger spring support plate (2 1/2")

---



### **CU-710-3: PLUNGER SPRING SUPPORT PLATE (3 1/4")**

Plunger spring support plate (3 1/4")

---



### **CU-711: PLUNGER RETURN SPRING**

Plunger return spring

---



### **CU-712-2: LOWER CYLINDER PLATE FOR 2 1/2" CUTTER**

Lower cylinder plate for 2 1/2" Cutter

---





**CU-712-3: LOWER CYLINDER PLATE FOR 3 1/4" CUTTER**

Lower cylinder plate

---



**CU-713-2: CUTTER AIR CYLINDER 2 1/2" DIAMETER**

Cutter air cylinder 2 1/2" diameter

---



**CU-713-3: CUTTER AIR CYLINDER 3 1/4" DIAMETER**

Cutter air cylinder 3 1/4" dia.

---



**CU-714-2: PISTON CUP SEAL 2 1/2"**

Piston cup seal 2 1/2" dia.

---



**CU-714-3: PISTON CUP SEAL 3 1/4" DIAMETER**

Piston cup seal 3 1/4" dia.

---



**CU-715-3: TOP PISTON CUP SEAL PLATE (ALUML)**

Top piston cup seal plate (aluml)

---



**CU-716-2: TOP PISTON CUP (2 1/2")**

Top piston cup (2 1/2")

---



**CU-716-3: TOP PISTON CUP (3 1/4")**

Top piston cup (3 1/4")

---



**CU-717-2: PISTON "O" RING BUMPER FOR 2 1/2" CYLINDER CUTTER**

Piston "O" ring bumper for 2 1/2" cylinder cutter

---



### **CU-717-3: PISTON "O" RING BUMPER FOR 3 1/4" CYLINDER CUTTER**

Piston "O" ring bumper for 3 1/4 cylinder cutter

---



### **CU-718-3: CYLINDER CLAMPING STUDS & NUTS (4/SET)**

Cylinder clamping studs & nuts (4/set)

---



### **CU-719: PIVOT ROD COLLAR**

Pivot rod collar

---



### **CU-720-2: TOP CYLINDER PLATE, 2 1/2"**

Top cylinder plate, 2 1/2"

---



### **CU-720-3: TOP CYLINDER PLATE, 3 1/4"**

Top cylinder plate, 3 1/4"

---



### **CU-721: STROKE ADJUSTING SCREW & LOCK NUT**

Stroke adjusting screw & lock nut

---



### **CU-722: PIVOT ROD TENSION SPRING**

Pivot rod tension spring

---



### **CU-723: PIVOT ROD TENSION SPRING COLLAR**

Pivot rod tension spring collar for 3 1/4 cylinder cutter

---



### **CU-725: PIVOT ROD LOCKING SCREW**

Pivot rod locking screw for 3 1/4 cylinder cutter

---



**CU-726-2: UPPER SUPPORT TUBE, 2 1/2"**

Upper support tube for 2 1/2" cylinder cutter

---



**CU-726-3: UPPER SUPPORT TUBE, 3 1/4"**

Upper support tube for 3 1/4 cylinder cutter

---



**CU-727: VERTICAL SWING STOP ADJUSTING ARM UNIT**

Vertical swing stop adjusting arm unit

---



**CU-728: HORIZONTAL ADJUSTING UNIT**

Horizontal adjusting unit

---



**CU-729: FINE ADJUSTING GUIDE WITH FINE ADJUST KNOB**

Fine adjusting guide with fine adjust knob

---



**CU-730: HEIGHT ADJUSTING COLLAR**

Height adjusting collar

---



**CU-731: CUTTER BASE UNIT**

Cutter base unit

---



**CU-732: CUTTER MOUNTING BARS**

Cutter mounting bars for 3 1/4 cylinder cutter

---



**CU-741: AIR INDEX PRESSURE NEEDLE VALVE AND ADJUSTING STUD**

Air index pressure needle valve and adjusting stud

---



**CU-746-PLC: AIR VALVE 24 VOLT**

Air valve 24 Volt

---



**CU-770: 2" FLAT CUTTER BLADE**

2" flat cutter blade

---

CUTTER DIES



CU-703: AIR PIN CUTTER DIE (CHOOSE SIZE AND ANGLE)

Air pin cutter die: 1", 1 1/4" or 1 1/2" O.D. and angle, 1 to 10 degrees. *Note: even-numbered angles are preferred.*

Variations

| Outer Diameter |
|----------------|
| 1"             |
| 1 1/4"         |
| 1 1/2"         |



CU-704: CUTTER DIES (CHOOSE SIZE AND ANGLE)

Action II cutter dies: 1", 1 1/4" or 1 1/2" O.D. and angle, 1 to 10 degrees. *Note: even-numbered angles are preferred.*

Variations

| Outer Diameter | Angle |
|----------------|-------|
| 1"             | 1     |
| 1"             | 2     |
| 1"             | 3     |
| 1"             | 4     |
| 1"             | 5     |
| 1"             | 6     |
| 1"             | 7     |
| 1"             | 8     |
| 1"             | 9     |
| 1"             | 10    |
| 1 1/4"         | 1     |
| 1 1/4"         | 2     |
| 1 1/4"         | 3     |
| 1 1/4"         | 4     |
| 1 1/4"         | 5     |

| Outer Diameter | Angle     |
|----------------|-----------|
| 1"             | Any Angle |
| 1 1/4"         | Any Angle |
| 1 1/2"         | Any Angle |

# COILER BASE COMPONENTS



**CABINET BASE**

Cabinet base - top and door not included

---



**CB-625: MOTOR MOUNT**

Motor mount

---



**CB-626: MOTOR ELEVATOR KNOB & ROD**

Motor elevator knob & rod

---



**CB-627: MOTOR LOCK-UP KNOB**

Motor lock-up knob

---



**PLC-120: VARIABLE-SPEED MOTOR - 3 PHASE, 1/2HP**

3-phase 1/2-horsepower variable-speed motor.

*Note: this part is not kept in stock. Orders may be delayed depending on availability.*

---



**PLC-121: VARIABLE-SPEED MOTOR - 3 PHASE, 1HP**

3-phase 1-horsepower variable-speed motor. For World Model 3000.

---



**WCB-611: MOTOR V BELT**

World Model 3000 motor V belt

---



**WCB-620: FULL COILER CABINET (INCLUDES TOP AND DOOR)**

Cabinet for World Model 3000 or Brute Coiler (includes top and door)

Specify Brute or World Model for accurate marking

---





**WCB-624V: MOTOR PULLEY FOR VARIABLE SPEED**

Motor pulley for variable speed

---



**WCB-629: FRICTION DRIVE GUARD**

Friction drive guard for World Model 3000

---

# COILING HEAD COMPONENTS



**WH-3000H: WORLD MODEL 3000 HEAD**

World Model 3000 head

---



**WH-3001: MAIN FRAME**

Main frame for WM 3000 coiling head

---



**WH-3002: FRONT TOP RAIL**

Front top rail for WM 3000 coiling head

---



**WH-3003: REAR TOP RAIL**

Rear top rail for WM 3000 coiling head

---



**WH-3005: SIDE PLATE LOCK KNOB**

Rear side plate lock knob for WM 3000 coiling head

---



**WH-3006: WEAR WASHER**

Wear washer for WM 3000 coiling head

---



**WH-3007: SLIDE LOCK BLOCK (EACH)**

Slide lock block (each) for WM 3000 coiling head

---



**WH-3008: SLIDE PINION (EACH)**

Slide pinion (each) for World Model 3000 coiling head

---



**WH-3009: PINION BEARING**

Pinion bearing for WM 3000 coiling head



### **WH-3010: HORIZONTAL ADJUST KNOB AND TAG**

Front horizontal adjust knob and tag for WM 3000 coiling head



### **WH-3012: FRONT ANGLE SECTOR**

Front angle sector for World Model 3000 coiling head



### **WH-3013: REAR ANGLE SECTOR**

Front angle sector for World Model 3000 coiling head



### **WH-3014: SECTOR CUPPED WASHER (EACH)**

Sector cupped washer (each) for World Model 3000 coiling head



### **WH-3015: JAM NUTS (EACH, 4 REQUIRED)**

Jam nuts (each, 4 required) for WM 3000 coiling head



### **WH-3016: FRONT OR REAR SIDE PLATE**

Front side plate for WM 3000 coiling head



### **WH-3018: FRONT SLIDE COVER BAR**

Front slide cover bar



### **WH-3019: FRONT COVER BAR RETAINER**

Front cover bar retainer for World Model 3000 coiling head



### **WH-3020: REAR SLIDE COVER BAR**

Rear slide cover bar for World Model 3000 coiling head



**WH-3021: FILLER BAR**

Filler bar for WM 3000 coiling head

---



**WH-3022: FLAT WASHER (EACH)**

Flat washer (each) for World Model 3000 coiling head

---



**WH-3023-A: NAME PLATE AND DEGREES FOR WM 3000 COILING HEAD**

Name plate and degree for WM 3000 coiling head

---



**WH-3023: TOP COVER & NAME PLATE**

Top cover & name plate for WM 3000 coiling head

---



**WH-3025: FRONT & REAR ROLL HANGER (SET)**

Front & rear roll hanger (set) for WM 3000 coiling head

---



**WH-3026: BALANCE SPRINGS (EACH, 2 REQUIRED)**

Balance springs (each, 2 required) for World Model 3000 coiling head

---



**WH-3027: HANGER PIVOT PIN FOR COILING HEAD (EACH)**

Hanger pivot pin (each) for WM 3000 coiling head

---



**WH-3028: SPRING TENSION ROLL PULL BAR ONLY**

Spring tension roll pull bar only for World Model 3000 coiling head

---



**WH-3028A: COMPLETE SPRING TENSION ROLL PULL BAR ASSEMBLY/  
WITH PULL BALLS**

Complete spring tension roll pull bar assembly/ with pull balls for WM 3000 coiling head

---



**WH-3029: SOLID TENSION ROLL PULL BAR**

Solid tension roll pull bar (bar only) for WM 3000 coiling head

---



**WH-3029A: COMPLETE SOLID TENSION ROLL PULL BAR ASSEMBLY WITH PULL BALLS**

Complete solid tension roll pull bar assembly with pull balls for WM 3000 coiling head

---



**WH-3030: FRONT & REAR PULL BALLS (2)**

Front & rear pull balls (2) for WM 3000 coiling head

---



**WH-3031: PULL BALL RETAINER SPRING**

Pull ball retainer spring for WM 3000 coiling head

---



**WH-3032: BALL RETAINER SCREWS & WASHERS**

Ball retainer screws & washers for WM 3000 coiling head

---



**WH-3033: COILING ROLL PULL BAR ADJUST KNOB**

Coiling roll pull bar adjust knob for WM 3000 coiling head

---



**WH-3034: COILING ROLL PULL BAR LOCK KNOB**

Coiling roll pull bar lock knob for WM 3000 coiling head

---



**WH-3035: ROLL BODY UNIT**

Roll body unit for WM 3000 coiling head

---



**WH-3035A: ROLL BODY ONLY**

Roll body only for WM 3000 coiling head

---



**WH-3036: SEALED ROLL BODY BEARINGS (SET)**

Sealed roll body bearings (set) for World Model 3000 coiling head

---



**WH-3037: ROLL CAP & SCREWS (SET) (2 SETS REQUIRED)**

Roll cap & screws (set) (2 sets required) for World Model 3000 coiling head

---



**WH-3038: PINION GEAR HOUSING - 14 TOOTH WITH BEARING**

Pinion gear housing 14 tooth with bearing

---



**WH-3039: PINION GEAR - 14 TOOTH**

14 tooth pinion gear

---



**WH-3040: PINION GEAR - 14 TOOTH - COMPLETE ASSEMBLY**

14 tooth pinion gear complete assembly

---



**WH-3041: PINION GEAR HOUSING - 22 TOOTH WITH BEARING**

Pinion gear housing 22 tooth with bearing

---



**WH-3042: PINION GEAR - 22 TOOTH**

22 tooth pinion gear for World Model 3000 coiling head

---



**WH-3043: PINION GEAR - 22 TOOTH - COMPLETE ASSEMBLY**

22 tooth pinion gear complete assembly for World Model 3000 coiling head

---



**WH-3044: PINION GEAR HOUSING - 54 TOOTH WITH BEARING**

Pinion gear housing 54 tooth with bearing

---



**WH-3045: PINION GEAR - 54 TOOTH**

54 tooth pinion gear for World Model 3000 coiling head

---



**WH-3046: PINION GEAR - 54 TOOTH - COMPLETE ASSEMBLY**

54 tooth pinion gear complete assembly for World Model 3000 coiling head

---



**WH-3047: NEEDLE BEARING (EACH)**

Needle bearing (each) for World Model 3000 coiling head

---



**WH-3048: PINION SHAFT COLLAR (EACH)**

Pinion shaft collar (each) for World Model 3000 coiling head

---



**WH-3049: IDLER GEAR (STEEL) & BEARING**

Idler gear (steel) & bearing for World Model 3000 coiling head

---



**WH-3050: IDLER GEAR BEARING SLEEVE**

Idler gear bearing sleeve for World Model 3000 coiling head

---



**WH-3051: GEAR GUARDS (SET)**

Gear guards (set) for World Model 3000 coiling head

---



**WH-3052: MICRO SWITCH & CORD**

Micro switch & cord for World Model 3000 coiling head

---



**WH-3053: MICRO SWITCH COVER**

Micro switch cover for World Model 3000 coiling head

---



**WH-3054: SAFETY SWITCH ASSEMBLY PARTS (SET)**

Safety switch assembly parts (set) for World Model 3000 coiling head

---



**WH-3055: SOLUTION WHEEL BRACKET**

Solution wheel bracket for World Model 3000 coiling head

---



**WH-3056: WIPER BLOCK HOLDER**

Wiper block holder for World Model 3000 coiling head

---



**WH-3057: RUBBER WIPER BLOCK**

Rubber wiper block for World Model 3000 coiling head

---



**WH-3058: SOLUTION WHEEL (EACH)**

Solution wheel (each) for World Model 3000 coiling head

---



**WH-3059: SOLUTION WHEEL BRACKET - COMPLETE ASSEMBLY**

Complete solution wheel bracket assembly (includes: WH-3055, WH3056, and WH-3058)

---



**WH-3060: SOLUTION WHEEL SLIDE ADJUSTING KNOB ASSEMBLY**

Solution wheel slide adjusting knob assembly for World Model 3000 coiling head

---



**WH-SHIM: SHIM, PLASTIC (2 PER TOP RAIL REQUIRED)**

Shim, plastic (2 per top rail required) state thickness: .003, .004, .005, .0075, .010.

---



# FRICTION DRIVE UNIT COMPONENTS



**WFD-301: ROCKER YOKE (H-FRAME)**

Rocker yoke (H-frame) for friction drive unit

---



**WFD-302: FRONT PIVOT ARM**

Front pivot arm for friction drive unit

---



**WFD-303: REAR PIVOT ARM**

Rear pivot arm for friction drive unit

---



**WFD-304: ROCKER PINS (EACH) (2 REQUIRED)**

Rocker pins (each) (2 required) for friction drive unit

---



**WFD-305: ROCKER STUD**

Rocker stud for friction drive unit

---



**WFD-306: FRICTION DRIVE PULL BAR**

Friction drive pull bar for friction drive unit

---



**WFD-307: FRICTION DRIVE PULL BAR PIVOT STUDS**

Friction drive pull bar pivot studs for friction drive unit

---



**WFD-308: FRICTION DRIVE PULL BAR ADJUSTING KNOB**

Friction drive pull bar adjusting knob for friction drive unit

---



**WFD-309: FRICTION DRIVE PULL BAR LOCKING KNOB**

Friction drive pull bar locking knob for friction drive unit



**WFD-310: FRICTION DRIVE HUB WITH BEARING & SEALS**

Friction drive hub with bearing & seals for friction drive unit



**WFD-311: NEEDLE BEARING (EACH)**

Needle bearing (each) for friction drive unit



**WFD-312: BEARING SEAL (EACH)**

Bearing seal (each) for friction drive unit



**WFD-313: TRU-ARC DRIVE SPINDLE SNAP RING(EACH)**

Tru-arc drive spindle snap ring for friction drive unit (each)



**WFD-314: DRIVE ROLL SPINDLE**

Drive roll spindle for friction drive unit



**WFD-315: BRONZE THRUST WASHER (EACH)**

Bronze thrust washer (each) for friction drive unit



**WFD-316: DRIVE HUB (EACH)**

Drive hub (each) for friction drive unit



**WFD-317: 6" FRICTION DRIVE ROLL (EACH)**

6" friction drive roll (each) for friction drive unit



**WFD-318: DRIVE ROLL SCREWS (8/SET)**

Drive roll screws (8/set) for friction drive unit



**WFD-319: DRIVE STUDS WITH NYLON SLEEVE (12/SET)**

Drive studs with nylon sleeve (12/set) for friction drive unit

---



**WFD-320: FLEXIBLE DRIVE CABLES (PAIR) 5/16"**

Flexible drive cables (pair) 5/16" for friction drive unit

---



**WFD-321: NYLON CABLE BUSHINGS**

Nylon cable bushings for friction drive unit

---



**WFD-322: FLEXIBLE DRIVE CABLES (PAIR) 3/8"**

3/8" flexible drive cables (pair) for friction drive unit

---



**WFD-323: FLEXIBLE DRIVE CABLES (PAIR) 1/2"**

1/2" flexible drive cables for friction drive unit

---

SPINDLE COMPONENTS



COLLETS: 100, 200 & 300 SERIES

Collets for spindle. 100 series compatible with Brute Coiler. 200 & 300 series compatible with World Model 3000.

Select series and size

Variations

| Series | Size  |
|--------|-------|
| 100    | 27/64 |
| 100    | 7/16  |
| 100    | 29/64 |
| 100    | 15/32 |
| 100    | 31/64 |
| 100    | 1/2   |
| 100    | 33/64 |
| 100    | 17/32 |
| 100    | 35/64 |
| 100    | 9/16  |
| 100    | 3/32  |
| 100    | 7/64  |
| 100    | 1/8   |
| 100    | 9/64  |
| 100    | 5/32  |
| 100    | 11/64 |
| 100    | 3/16  |
| 100    | 13/64 |
| 100    | 5/16  |
| 100    | 21/64 |
| 100    | 11/32 |
| 100    | 23/64 |
| 100    | 3/8   |

| Series | Size  |
|--------|-------|
| 100    | 25/64 |
| 100    | 13/32 |
| 100    | 19/64 |
| 100    | 21/64 |
| 100    | 5/16  |
| 100    | 9/32  |
| 100    | 17/64 |
| 100    | 1/4   |
| 100    | 15/64 |
| 100    | 7/32  |
| 200    | 23/64 |
| 200    | 11/32 |
| 200    | 17/64 |
| 200    | 19/64 |
| 200    | 21/64 |
| 200    | 3/8   |
| 200    | 5/16  |

[To see all Variations click here](#)



**CS-515: COLLET FLAT & SOCKET WRENCH SET**

Collet flat & socket wrench set for spindle unit



**WCS-501-A: COMPLETE COLLET SPINDLE ASSEMBLY**

Complete collet spindle assembly for spindle unit



**WCS-502: MAIN COLLET SPINDLE WITH NOSE CAP**

Main collet spindle with nose cap for spindle unit



**WCS-503: REAR RETAINER NUT**

Rear retainer nut for spindle unit

---



**WCS-504: REAR BEARING HOUSING**

Front & rear bearing housing for spindle unit

---



**WCS-504A: FRONT & REAR BEARING HOUSING**

Front & rear bearing housing for spindle unit

---



**WCS-505: FRONT BEARING HOUSING**

Front bearing housing for spindle unit

---



**WCS-506: FRONT SPINDLE NUT**

Front spindle nut for spindle unit

---



**WCS-507: FRONT OR REAR SPINDLE BEARING (EACH)**

Front or rear spindle bearing each for spindle unit

---



**WCS-508: TRU-ARCS EACH (2 IN FRONT/2 IN REAR)**

Tru-arcs each (2 in front/2 in rear) for spindle unit

---



**WCS-509: 5-STEP SPINDLE PULLEY**

5-step spindle pulley for spindle unit

---



**WCS-510: WAVE WASHER (EACH)**

Wave washer for spindle unit (each)

---



**WCS-511: SNAP RING**

Snap ring for spindle unit

---



**WCS-512: HELIX ANGLE YOKE ASSEMBLY**

Helix angle yoke assembly for spindle unit

---



**WCS-513: HELIX ANGLE YOKE BALLS (NYLON) (EACH)**

Helix angle yoke balls (nylon) each for spindle unit

---



**WCS-514: HELIX BALL SCREWS (EACH)**

Helix ball screws each for spindle unit

---



**WCS-516-1: DRIVE COLLAR LINER**

Drive collar liner for spindle unit

---



**WCS-516: DRIVE COLLAR & LINER (SET)**

Drive collar & liner set for spindle unit

---



**WCS-518: DRIVE SLEEVE SET (7 PER SET, 3/4" - 2")**

Drive sleeve set (7 per set, 3/4" - 2") for spindle unit

---



**WCS-519: 3/4" DRIVE SLEEVE**

3/4" drive sleeve for spindle unit

---



**WCS-520: 7/8" DRIVE SLEEVE**

7/8" drive sleeve for spindle unit

---



**WCS-521: 1" DRIVE SLEEVE**

1" drive sleeve for spindle unit

---



**WCS-522: 1 1/4" DRIVE SLEEVE FOR SPINDLE UNIT**

1 1/4" drive sleeve for spindle unit

---



**WCS-523: 1 1/2" DRIVE SLEEVE FOR SPINDLE UNIT**

1 1/2" drive sleeve for spindle unit

---



**WCS-525: 2" DRIVE SLEEVE**

2" drive sleeve for spindle unit

---



DRIVE SLEEVES



**WCS-518: DRIVE SLEEVE SET (7 PER SET, 3/4" - 2")**

Drive sleeve set (7 per set, 3/4" - 2") for spindle unit

---



**WCS-519: 3/4" DRIVE SLEEVE**

3/4" drive sleeve for spindle unit

---



**WCS-520: 7/8" DRIVE SLEEVE**

7/8" drive sleeve for spindle unit

---



**WCS-521: 1" DRIVE SLEEVE**

1" drive sleeve for spindle unit

---



**WCS-522: 1 1/4" DRIVE SLEEVE FOR SPINDLE UNIT**

1 1/4" drive sleeve for spindle unit

---



**WCS-523: 1 1/2" DRIVE SLEEVE FOR SPINDLE UNIT**

1 1/2" drive sleeve for spindle unit

---



**WCS-524: 1 3/4" DRIVE SLEEVE**

1 3/4" drive sleeve for spindle unit

---



**WCS-525: 2" DRIVE SLEEVE**

2" drive sleeve for spindle unit

---



**WCS-526: 2 1/4" DRIVE SLEEVE**

2 1/4" drive sleeve for spindle unit

*Note: these items are not kept in stock. Orders may be delayed depending on availability.*



### **WCS-527: 2 1/2" DRIVE SLEEVE**

2 1/2" drive sleeve for spindle unit

*Note: these items are not kept in stock. Orders may be delayed depending on availability.*

---



### **WFD-319: DRIVE STUDS WITH NYLON SLEEVE (12/SET)**

Drive studs with nylon sleeve (12/set) for friction drive unit

---

## NOSE CAPS



**NC-300: 300 SERIES COLLET NOSE CAP**

Nose cap for use with 300 series collets

---



**NC: COLLET NOSE CAP (100 OR 200 SERIES)**

Nose cap for use with collets. Please select 100 or 200 series.

---

**Variations**

| Collet Series |
|---------------|
| 100           |
| 200           |

## GATE COMPONENTS



**GT-900: COMPLETE 6' GATE**

Complete 6' gate

---



**GT-901: 6' COIL TRAY & SUPPORT FOOT**

6' coil tray & support foot

---



**GT-902: 6' TRAY GATE HINGE**

Gate hinge - 6' tray. Replacement hinge must be fit to coil tray.


---



**GT-903: GATE HINGE SUPPORT (EACH)**

Gate hinge support (each)

---



**GT-904: HINGE OPERATOR LEVER**

Hinge operator lever

---



**GT-905: GATE AIR CYLINDER MOUNT PLATE**

Gate air cylinder mount plate

---



**GT-906: GATE CYLINDER SUPPORT BLOCK/STUDS**

Gate cylinder support block/studs

---



**GT-907: GATE AIR CYLINDER**

Gate air cylinder

---




**GT-908: GATE ELECTRO PNEUMATIC VALVE**

Gate electro pneumatic valve. Choose current type: AC or DC.

---

Variations

| Current Type |
|--------------|
| AC           |
| DC           |



**GT-915-1: GATE SADDLE**

Gate saddle


---



**GT-915-2: SADDLE SUPPORT**

Saddle support

---



**GT-915-2A: SADDLE ADJUST BLOCK**

Saddle adjust block

---



**GT-915-3: LEG MOUNT PLATE**

Leg mount plate

---



**GT-915-4: TRI-POD LEGS (SET OF 3)**

Tri-pod legs (set of 3)

---



**GT-915-5: RUBBER FOOT CUP FOR TRI-POD LEG**

Rubber foot cup for tri-pod leg

---



**GT-915: GATE SUPPORT TRI-POD COMPLETE**

Gate support tri-pod complete

---



**GT-916: GATE SLIDE CLAMP**

Gate slide clamp

---



**GT-917: GATE SLIDE**

Gate slide

---



**GT-918: GATE SUPPORT FOOT**

Gate support foot

---



**GT-930: 3' GATE - COMPLETE**

Complete 3' gate

---



**GT-931: 3' COIL TRAY**

3' coil tray

---



**GT-932: 3' GATE HINGE**

3' gate hinge. Replacement hinge must be fit to coil tray.

---



**GT-935: 3' GATE EXTENSION WITHOUT TRI-POD**

3' gate extension without tri-pod

---



**GT-966: 12' GATE - COMPLETE**

Complete 12' gate

---



**GT-968: 6' GATE EXTENSION WITH TRI-POD**

6' gate extension with tri-pod

---

# ISOLATOR UNIT COMPONENTS



**IU-200: COMPLETE ISOLATOR UNIT**

Complete isolator unit

---



**IU-201: ISOLATOR MOUNTING PLATE**

Isolator mounting plate

---



**IU-202: ISOLATOR MOUNTING BOLTS**

Isolator mounting bolts

---



**IU-203: METERING SHAFT HOUSING**

Metering shaft housing

---



**IU-204: SNAP RING METERING SHAFT HOUSING**

Snap ring metering shaft housing

---



**IU-205: METERING WHEEL SHAFT W/ BEARINGS**

Metering wheel shaft w/ bearings

---



**IU-206: METERING WHEEL**

Metering wheel

---



**IU-207: METERING WHEEL "O" RING**

Metering wheel "O" ring

---



**IU-208: TENSION ARM LOCK & STUD**

Tension arm lock & stud



**IU-209: TENSION ARM COLLAR**

Tension arm collar



**IU-210: TENSION ADJUST SPRING & STUD**

Tension adjust spring & stud



**IU-211: TENSION STUD BLOCK**

Tension stud block



**IU-212: BRAKE ARM & TENSION BLOCK STUDS (SET)**

Brake arm & tension block studs (set)



**IU-213: BRAKE DISC ARM**

Brake disc arm



**IU-214: BRAKE DISC**

Brake disc



**IU-215: BRAKE PRESSURE SPRING**

Brake pressure spring



**IU-216: SAFETY SWITCH TRIP ARM**

Safety switch trip arm



**IU-217: MICRO SWITCH AND COVER AND CORD SET**

Micro switch, cover and cord set





**IU-218: MICRO SWITCH COVER**

Micro switch cover

---



**IU-219: ENCODER 400 PULSE**

Encoder 400 pulse

---



**IU-220: FLEXIBLE ENCODER SHAFT**

Flexible encoder shaft

---



**IU-221: WIRE GUIDE WHEEL (EACH)**

Wire guide wheel (each)

---



**IU-222: ENCODER 100 PULSE**

Encoder 100 pulse

*Note: these items are not kept in stock. Orders may be delayed depending on availability.*

---



**IU-223: ENCODER 200 PULSE**

Encoder 200 pulse

*Note: these items are not kept in stock. Orders may be delayed depending on availability.*

---



**IU-224: ENCODER CABLE & PLUG**

Encoder cable & plug

---

PLC AND ELECTRICAL COMPONENTS

CABLES AND CONNECTORS



**PLC-112: MINIFAST CABLE FOR MOTOR**

Minifast cable for motor

---



**PLC-113: JUNCTION BOX CORD**

Junction box cord

---



**PLC-114: TOUCH SCREEN CABLE - LEGACY**

Touch screen cable

*Note: this cable is compatible with the legacy version of the touch screen (PLC-107).*

---



**PLC-116: BULKHEAD CONNECTOR FOR MOTOR**

Bulkhead connector for motor

---



**PLC-117: BULKHEAD CONNECTOR TO JUNCTION BOX**

Bulkhead connector to junction box

---



**PLC-118: COMPONENT CORD**

Component cord

---



**PLC-214: TOUCH SCREEN CABLE**

Touch screen cable (ethernet)

---

## ELECTRICAL CONTROL UNIT COMPONENTS



### PLC-100: ELECTRICAL BOX (COMPLETE UNIT) - LEGACY

Electrical box (complete unit) - Legacy. Includes air valves.

*Note: this is for the previous version of the Platt Coiler PLC. For the current version, see [plc-200](#).*

---



### PLC-101: ELECTRICAL BOX (LEGACY)

Electrical box - Legacy.

*Note: this is for the previous version of the Platt Coiler PLC.*

---



### PLC-102: ELECTRICAL BOX COVER (LEGACY)

Electrical box cover - Legacy.

*Note: this is for the previous version of the Platt Coiler PLC. For the current version, see [plc 202](#).*

---



### PLC-106: PLC CONTROL UNIT (FPO-A21)

Control unit (FPO-A21)

---



### PLC-107: TOUCH SCREEN (LEGACY)

Touch screen (Legacy)

*Note: this touch screen is a legacy version. For the newest version, see PLC-207.*

---



### PLC-108: I/O MODULAR (LEGACY)

I/O Modular

*Note: this is for the previous version of the Platt Coiler PLC.*

---



### PLC-109: CONTROL UNIT (LEGACY)

Control Unit - Legacy

*Note: this is for the previous version of the Platt Coiler PLC.*

---



**PLC-110: 24V POWER SUPPLY**

24V power supply

---



**PLC-111: JUNCTION BOX**

Junction box

---



**PLC-119: EMERGENCY STOP BUTTON AND TAG (LEGACY)**

Emergency stop button and tag

*This part is compatible with the legacy version of the PLC (PLC-107)*

---



**PLC-200: ELECTRICAL BOX (COMPLETE UNIT)**

Electrical box (complete unit). Includes air valves.

---



**PLC-202: ELECTRICAL BOX**

Electrical box. Includes door.

---



**PLC-207: TOUCH SCREEN**

Touch screen (allen-bradley)

---



**PLC-209: PLC UNIT**

PLC Unit

---



**PLC-219: EMERGENCY STOP BUTTON**

Emergency stop button

---

# MOTORS AND MOTOR COMPONENTS



**PLC-120: VARIABLE-SPEED MOTOR - 3 PHASE, 1/2HP**

3-phase 1/2-horsepower variable-speed motor.

*Note: this part is not kept in stock. Orders may be delayed depending on availability.*

---



**PLC-121: VARIABLE-SPEED MOTOR - 3 PHASE, 1HP**

3-phase 1-horsepower variable-speed motor. For World Model 3000.

---



**PLC-122: AC DRIVE 1HP 120V (LEGACY)**

AC drive 1-horsepower 120 Volt

*This part is compatible with the legacy version of the PLC (PLC-107)*

---



**PLC-123: AC DRIVE 220V INPUT**

AC drive 220V input

*This part is compatible with the legacy version of the PLC (PLC-107)*

---



**PLC-222: AC DRIVE 1HP 120 VOLTS**

AC drive 1HP 120 Volt

---



**PLC-223: AC DRIVE 1HP 220 VOLTS**

AC drive 1HP 220 Volts

---

SPOOL TOWER COMPONENTS



ST-001: SPOOL TOWER AND BRACKET

Spool tower and bracket

---



ST-002: SPOOL TOWER BOLT

Spool tower bolt

---



ST-003: COMPLETE DEPAILER UNIT

Complete depailer unit

---



ST-005: SPOOL SPINDLE

Spool spindle

---



ST-006: SPOOL SPINDLE KNOBS (2)

Spool spindle knobs (2)

---



ST-007: INNER & OUTER BRAKE PADS (SET)

Inner & outer brake pads (set)

---



ST-008: NYLON GUIDES (DOZEN)

Nylon guides (dozen)

---



ST-009: MACHINE LIGHT

Machine light

---



ST-010: MAGNIFYING LENS

Magnifying lens



## INDEX

### C

|                                                             |    |
|-------------------------------------------------------------|----|
| Cabinet Base                                                | 10 |
| CB-625: Motor Mount                                         | 10 |
| CB-626: Motor Elevator Knob & Rod                           | 10 |
| CB-627: Motor Lock-Up Knob                                  | 10 |
| Collets: 100, 200 & 300 SERIES                              | 22 |
| CS-515: Collet Flat & Socket Wrench Set                     | 23 |
| CU-700-2: 2 1/2" Cylinder Air Cutter, Complete              | 2  |
| CU-700-3: 3 1/4 Cylinder Air Cutter, Complete               | 2  |
| CU-701-2: Cutter Die Block with 1" Hole                     | 2  |
| CU-701-3: Cutter Die Block with 1 1/4" Hole                 | 2  |
| CU-702: Die Locking Stud for 3 1/4 Cylinder Cutter          | 2  |
| CU-703: Air Pin Cutter Die (Choose Size and Angle)          | 8  |
| CU-704: Cutter Dies (Choose Size and Angle)                 | 8  |
| CU-705-3: Cutter Blade Round 2" Dia.                        | 2  |
| CU-706: Cutter Blade Screw And Nut                          | 2  |
| CU-707-2: Cutter Blade Holder (1 1/2")                      | 2  |
| CU-707-3: Cutter Blade Holder                               | 3  |
| CU-708-2: Plunger Bars for 2 1/2" Cutter (2 Parts)          | 3  |
| CU-708-3: Plunger Bars - 3 In. Cylinder                     | 3  |
| CU-709-2: Die Block Support Rods & Nuts (Set)               | 3  |
| CU-709-3: Die Block Support Rods & Nuts (Set)               | 3  |
| CU-710-2: Plunger Spring Support Plate (2 1/2")             | 3  |
| CU-710-3: Plunger Spring Support Plate (3 1/4")             | 3  |
| CU-711: Plunger Return Spring                               | 3  |
| CU-712-2: Lower Cylinder Plate for 2 1/2" Cutter            | 3  |
| CU-712-3: Lower Cylinder Plate for 3 1/4" Cutter            | 4  |
| CU-713-2: Cutter Air Cylinder 2 1/2" Diameter               | 4  |
| CU-713-3: Cutter Air Cylinder 3 1/4" Diameter               | 4  |
| CU-714-2: Piston Cup Seal 2 1/2"                            | 4  |
| CU-714-3: Piston Cup Seal 3 1/4" Diameter                   | 4  |
| CU-715-3: Top Piston Cup Seal Plate (Alum)                  | 4  |
| CU-716-2: Top Piston Cup (2 1/2")                           | 4  |
| CU-716-3: Top Piston Cup (3 1/4")                           | 4  |
| CU-717-2: Piston "O" Ring Bumper for 2 1/2" Cylinder Cutter | 4  |
| CU-717-3: Piston "O" Ring Bumper for 3 1/4" Cylinder Cutter | 5  |
| CU-718-3: Cylinder Clamping Studs & Nuts (4/Set)            | 5  |
| CU-719: Pivot Rod Collar                                    | 5  |
| CU-720-2: Top Cylinder Plate, 2 1/2"                        | 5  |
| CU-720-3: Top Cylinder Plate, 3 1/4"                        | 5  |
| CU-721: Stroke Adjusting Screw & Lock Nut                   | 5  |
| CU-722: Pivot Rod Tension Spring                            | 5  |
| CU-723: Pivot Rod Tension Spring Collar                     | 5  |
| CU-725: Pivot Rod Locking Screw                             | 5  |
| CU-726-2: Upper Support Tube, 2 1/2"                        | 6  |
| CU-726-3: Upper Support Tube, 3 1/4"                        | 6  |
| CU-727: Vertical Swing Stop Adjusting Arm Unit              | 6  |
| CU-728: Horizontal Adjusting Unit                           | 6  |



CU-729: Fine Adjusting Guide with Fine Adjust Knob 6  
CU-730: Height Adjusting Collar 6  
CU-731: Cutter Base Unit 6  
CU-732: Cutter Mounting Bars 6  
CU-741: Air Index Pressure Needle Valve And Adjusting Stud 6  
CU-746-PLC: Air Valve 24 Volt 7  
CU-770: 2" Flat Cutter Blade 7

### G

GT-900: Complete 6' Gate 30  
GT-901: 6' Coil Tray & Support Foot 30  
GT-902: 6' Tray Gate Hinge 30  
GT-903: Gate Hinge Support (Each) 30  
GT-904: Hinge Operator Lever 30  
GT-905: Gate Air Cylinder Mount Plate 30  
GT-906: Gate Cylinder Support Block/Studs 30  
GT-907: Gate Air Cylinder 30  
GT-908: Gate Electro Pneumatic Valve 30  
GT-915-1: Gate Saddle 31  
GT-915-2: Saddle Support 31  
GT-915-2A: Saddle Adjust Block 31  
GT-915-3: Leg Mount Plate 31  
GT-915-4: Tri-Pod Legs (Set Of 3) 31  
GT-915-5: Rubber Foot Cup for Tri-Pod Leg 31  
GT-915: Gate Support Tri-Pod Complete 31  
GT-916: Gate Slide Clamp 31  
GT-917: Gate Slide 32  
GT-918: Gate Support Foot 32  
GT-930: 3' Gate - Complete 32  
GT-931: 3' Coil Tray 32  
GT-932: 3' Gate Hinge 32  
GT-935: 3' Gate Extension Without Tri-Pod 32  
GT-966: 12' Gate - Complete 32  
GT-968: 6' Gate Extension With Tri-Pod 32

### I

IU-200: Complete Isolator Unit 33  
IU-201: Isolator Mounting Plate 33  
IU-202: Isolator Mounting Bolts 33  
IU-203: Metering Shaft Housing 33  
IU-204: Snap Ringmetering Shaft Housing 33  
IU-205: Metering Wheel Shaft W/ Bearings 33  
IU-206: Metering Wheel 33  
IU-207: Metering Wheel "O" Ring 33  
IU-208: Tension Arm Lock & Stud 33  
IU-209: Tension Arm Collar 34  
IU-210: Tension Adjust Spring & Stud 34  
IU-211: Tension Stud Block 34  
IU-212: Brake Arm & Tension Block Studs (Set) 34  
IU-213: Brake Disc Arm 34  
IU-214: Brake Disc 34  
IU-215: Brake Pressure Spring 34  
IU-216: Safety Switch Trip Arm 34

IU-217: Micro Switch and Cover and Cord Set 34  
IU-218: Micro Switch Cover 35  
IU-219: Encoder 400 Pulse 35  
IU-220: Flexible Encoder Shaft 35  
IU-221: Wire Guide Wheel (Each) 35  
IU-222: Encoder 100 Pulse 35  
IU-223: Encoder 200 Pulse 35  
IU-224: Encoder Cable & Plug 35

### N

NC-300: 300 Series Collet Nose Cap 29  
NC: Collet Nose Cap (100 or 200 Series) 29

### P

PLC-100: Electrical Box (Complete Unit) - Legacy 37  
PLC-101: Electrical Box (Legacy) 37  
PLC-102: Electrical Box Cover (Legacy) 37  
PLC-106: PLC Control Unit (FPO-A21) 37  
PLC-107: Touch Screen (Legacy) 37  
PLC-108: I/O Modular (Legacy) 37  
PLC-109: Control Unit (Legacy) 37  
PLC-110: 24V Power Supply 38  
PLC-111: Junction Box 38  
PLC-112: Minifast Cable For Motor 36  
PLC-113: Junction Box Cord 36  
PLC-114: Touch Screen Cable - Legacy 36  
PLC-116: Bulkhead Connector for Motor 36  
PLC-117: Bulkhead Connector to Junction Box 36  
PLC-118: Component Cord 36  
PLC-119: Emergency Stop Button And Tag (Legacy) 38  
PLC-120: Variable-Speed Motor - 3 Phase, 1/2HP 10, 39  
PLC-121: Variable-Speed Motor - 3 Phase, 1HP 10, 39  
PLC-122: AC Drive 1HP 120V (Legacy) 39  
PLC-123: AC Drive 220V Input 39  
PLC-200: Electrical Box (Complete Unit) 38  
PLC-202: Electrical Box 38  
PLC-207: Touch Screen 38  
PLC-209: PLC Unit 38  
PLC-214: Touch Screen Cable 36  
PLC-219: Emergency Stop Button 38  
PLC-222: AC Drive 1HP 120 Volts 39  
PLC-223: AC Drive 1HP 220 Volts 39

### S

ST-001: Spool Tower And Bracket 40  
ST-002: Spool Tower Bolt 40  
ST-003: Complete Depailer Unit 40  
ST-005: Spool Spindle 40  
ST-006: Spool Spindle Knobs (2) 40  
ST-007: Inner & Outer Brake Pads (Set) 40  
ST-008: Nylon Guides (Dozen) 40  
ST-009: Machine Light 40  
ST-010: Magnifying Lens 40

### W

|                                                      |        |
|------------------------------------------------------|--------|
| WCB-611: Motor V Belt                                | 10     |
| WCB-620: Full Coiler Cabinet (Includes Top and Door) | 10     |
| WCB-624V: Motor Pulley for Variable Speed            | 11     |
| WCB-629: Friction Drive Guard                        | 11     |
| WCS-501-A: Complete Collet Spindle Assembly          | 23     |
| WCS-502: Main Collet Spindle With Nose Cap           | 23     |
| WCS-503: Rear Retainer Nut                           | 24     |
| WCS-504: Rear Bearing Housing                        | 24     |
| WCS-504A: Front & Rear Bearing Housing               | 24     |
| WCS-505: Front Bearing Housing                       | 24     |
| WCS-506: Front Spindle Nut                           | 24     |
| WCS-507: Front Or Rear Spindle Bearing (Each)        | 24     |
| WCS-508: Tru-Arcs Each (2 In Front/2 In Rear)        | 24     |
| WCS-509: 5-Step Spindle Pulley                       | 24     |
| WCS-510: Wave Washer (Each)                          | 24     |
| WCS-511: Snap Ring                                   | 25     |
| WCS-512: Helix Angle Yoke Assembly                   | 25     |
| WCS-513: Helix Angle Yoke Balls (Nylon) (Each)       | 25     |
| WCS-514: Helix Ball Screws (Each)                    | 25     |
| WCS-516-1: Drive Collar Liner                        | 25     |
| WCS-516: Drive Collar & Liner (Set)                  | 25     |
| WCS-518: Drive Sleeve Set (7 Per Set, 3/4" - 2")     | 25, 27 |
| WCS-519: 3/4" Drive Sleeve                           | 25, 27 |
| WCS-520: 7/8" Drive Sleeve                           | 25, 27 |
| WCS-521: 1" Drive Sleeve                             | 26, 27 |
| WCS-522: 1 1/4" Drive Sleeve for Spindle Unit        | 26, 27 |
| WCS-523: 1 1/2" Drive Sleeve for Spindle Unit        | 26, 27 |
| WCS-524: 1 3/4" Drive Sleeve                         | 27     |
| WCS-525: 2" Drive Sleeve                             | 26, 27 |
| WCS-526: 2 1/4" Drive Sleeve                         | 27     |
| WCS-527: 2 1/2" Drive Sleeve                         | 28     |
| WFD-301: Rocker Yoke (H-Frame)                       | 19     |
| WFD-302: Front Pivot Arm                             | 19     |
| WFD-303: Rear Pivot Arm                              | 19     |
| WFD-304: Rocker Pins (Each) (2 Required)             | 19     |
| WFD-305: Rocker Stud                                 | 19     |
| WFD-306: Friction Drive Pull Bar                     | 19     |
| WFD-307: Friction Drive Pull Bar Pivot Studs         | 19     |
| WFD-308: Friction Drive Pull Bar Adjusting Knob      | 19     |
| WFD-309: Friction Drive Pull Bar Locking Knob        | 19     |
| WFD-310: Friction Drive Hub With Bearing & Seals     | 20     |
| WFD-311: Needle Bearing (Each)                       | 20     |
| WFD-312: Bearing Seal (Each)                         | 20     |
| WFD-313: Tru-Arc Drive Spindle Snap Ring(Each)       | 20     |
| WFD-314: Drive Roll Spindle                          | 20     |
| WFD-315: Bronze Thrust Washer (Each)                 | 20     |
| WFD-316: Drive Hub (Each)                            | 20     |
| WFD-317: 6" Friction Drive Roll (Each)               | 20     |
| WFD-318: Drive Roll Screws (8/Set)                   | 20     |
| WFD-319: Drive Studs With Nylon Sleeve (12/Set)      | 21, 28 |
| WFD-320: Flexible Drive Cables (Pair) 5/16"          | 21     |

|                                                                           |    |
|---------------------------------------------------------------------------|----|
| WFD-321: Nylon Cable Bushings                                             | 21 |
| WFD-322: Flexible Drive Cables (Pair) 3/8"                                | 21 |
| WFD-323: Flexible Drive Cables (Pair) 1/2"                                | 21 |
| WH-3000H: World Model 3000 Head                                           | 12 |
| WH-3001: Main Frame                                                       | 12 |
| WH-3002: Front Top Rail                                                   | 12 |
| WH-3003: Rear Top Rail                                                    | 12 |
| WH-3005: Side Plate Lock Knob                                             | 12 |
| WH-3006: Wear Washer                                                      | 12 |
| WH-3007: Slide Lock Block (Each)                                          | 12 |
| WH-3008: Slide Pinion (Each)                                              | 12 |
| WH-3009: Pinion Bearing                                                   | 12 |
| WH-3010: Horizontal Adjust Knob and Tag                                   | 13 |
| WH-3012: Front Angle Sector                                               | 13 |
| WH-3013: Rear Angle Sector                                                | 13 |
| WH-3014: Sector Cupped Washer (Each)                                      | 13 |
| WH-3015: Jam Nuts (Each, 4 Required)                                      | 13 |
| WH-3016: Front or Rear Side Plate                                         | 13 |
| WH-3018: Front Slide Cover Bar                                            | 13 |
| WH-3019: Front Cover Bar Retainer                                         | 13 |
| WH-3020: Rear Slide Cover Bar                                             | 13 |
| WH-3021: Filler Bar                                                       | 14 |
| WH-3022: Flat Washer (Each)                                               | 14 |
| WH-3023-A: Name Plate and Degrees for WM 3000 Coiling Head                | 14 |
| WH-3023: Top Cover & Name Plate                                           | 14 |
| WH-3025: Front & Rear Roll Hanger (Set)                                   | 14 |
| WH-3026: Balance Springs (Each, 2 Required)                               | 14 |
| WH-3027: Hanger Pivot Pin for Coiling Head (Each)                         | 14 |
| WH-3028: Spring Tension Roll Pull Bar Only                                | 14 |
| WH-3028A: Complete Spring Tension Roll Pull Bar Assembly/ with Pull Balls | 14 |
| WH-3029: Solid Tension Roll Pull Bar                                      | 15 |
| WH-3029A: Complete Solid Tension Roll Pull Bar Assembly with Pull Balls   | 15 |
| WH-3030: Front & Rear Pull Balls (2)                                      | 15 |
| WH-3031: Pull Ball Retainer Spring                                        | 15 |
| WH-3032: Ball Retainer Screws & Washers                                   | 15 |
| WH-3033: Coiling Roll Pull Bar Adjust Knob                                | 15 |
| WH-3034: Coiling Roll Pull Bar Lock Knob                                  | 15 |
| WH-3035: Roll Body Unit                                                   | 15 |
| WH-3035A: Roll Body Only                                                  | 15 |
| WH-3036: Sealed Roll Body Bearings (Set)                                  | 16 |
| WH-3037: Roll Cap & Screws (Set) (2 Sets Required)                        | 16 |
| WH-3038: Pinion Gear Housing - 14 Tooth With Bearing                      | 16 |
| WH-3039: Pinion Gear - 14 Tooth                                           | 16 |
| WH-3040: Pinion Gear - 14 Tooth - Complete Assembly                       | 16 |
| WH-3041: Pinion Gear Housing - 22 Tooth With Bearing                      | 16 |
| WH-3042: Pinion Gear - 22 Tooth                                           | 16 |
| WH-3043: Pinion Gear - 22 Tooth - Complete Assembly                       | 16 |
| WH-3044: Pinion Gear Housing - 54 Tooth With Bearing                      | 16 |
| WH-3045: Pinion Gear - 54 Tooth                                           | 17 |
| WH-3046: Pinion Gear - 54 Tooth - Complete Assembly                       | 17 |
| WH-3047: Needle Bearing (Each)                                            | 17 |
| WH-3048: Pinion Shaft Collar (Each)                                       | 17 |
| WH-3049: Idler Gear (Steel) & Bearing                                     | 17 |

|                                                       |    |
|-------------------------------------------------------|----|
| WH-3050: Idler Gear Bearing Sleeve                    | 17 |
| WH-3051: Gear Guards (Set)                            | 17 |
| WH-3052: Micro Switch & Cord                          | 17 |
| WH-3053: Micro Switch Cover                           | 17 |
| WH-3054: Safety Switch Assembly Parts (Set)           | 18 |
| WH-3055: Solution Wheel Bracket                       | 18 |
| WH-3056: Wiper Block Holder                           | 18 |
| WH-3057: Rubber Wiper Block                           | 18 |
| WH-3058: Solution Wheel (Each)                        | 18 |
| WH-3059: Solution Wheel Bracket - Complete Assembly   | 18 |
| WH-3060: Solution Wheel Slide Adjusting Knob Assembly | 18 |
| WH-SHIM: Shim, Plastic (2 Per Top Rail Required)      | 18 |



**CONTACT US**

**+1-800-933-0404**

**sales@plattcoiler.com**

**www.plattcoiler.com**



The Leader in the  
Electric Coil Heating Industry  
Since 1953



SCAN TO SHOP ONLINE

